

Vektek-Keyence Electronic Pressure Switch



1. See Page 2 for default settings for the pressure switch.
2. See Included Keyence Manual for instructions on changing any of the default settings



P/N.: 70-7507-71, 70-7507-73



Specifications are subject to changes without notice!

		IS	7077
REV.	A	EFF. DATE	RELEASE
ECN NO.		4543	
BY / DATE:		ALS	11/3/21
APPR. / DATE:			
REV APPR. / DATE:			

VEKTEK LLC
1334 E. 6th Ave
Emporia, Ks 66801
USA
Phone: 913-365-1045 (sales)
Fax: 816-364-0471 (sales)
620-342-7637 (technical service)
Email: sales@vektek.com
Website: www.vektek.com

Navigation function	Symbol (keys)
Menu descending	▽
Menu ascending	△
Select Menu Item	Mode

Parameter	Display	Default
Units (PSI, bar, MPA)	Unit	PSI
Switch-on Point 1 (SP1)	SP1	5000 PSI
Switch-off Point 1 (rP1)	rP1	4500 PSI
Hysteresis 1 (Normally Open Hno, Normally Closed Hnc)	Hn1	Hno
Analog Start Point	ASP	0 PSI
Analog End Point	REP	5800 PSI
Offset Correction	COF	0 PSI
On Delay Timer of Output 1	DS1	0 s
Off Delay Timer of Output 1	DR2	0 s
Responsiveness	SPEd	3 s
Power Save Mode	ECO	Off
Update of Measuring Value on Display	DISU	200 ms
Display Rotation	DISr	Yes
Password	PASS	0000
Polarity of Control Output	P-n	PnP