



1

2


CENTER SCREW



HANDLE



Handle here in position B  
A to T



Handle here in position A  
P to A

To Reposition Handle:

1. Remove center screw
2. Take off and reposition handle
3. Apply low strength loctite to center screw
4. Torque center screw to 20 in-lbs

B

B

A

A

### INSTALLATION INSTRUCTIONS



VEKTEK, INC.  
1334 E. SIXTH AVE. P.O. BOX 625  
EMPORIA, KS. 66801 U.S.A.

ASSEMBLIES AFFECTED

71-1422-04

47-1142-21

INSTRUCTION SHEET, VALVE, WNL, MANIFOLD, 2/3

SIZE  
A

1S7120

REV  
A

FORM FEG041-IS-ASIZE, REV. B

A	3892	RELEASE	ALS	08/08/19
REV	IN ACCORDANCE WITH ECN	EFFECTIVE DATE	REVISED BY	DATE
DRW BY:	ALS	<b>DRAWING STATUS: Released</b>		
DATE:	08/08/19	PRODUCTION APPROVED FOR RELEASED STATUS ONLY		

1

2

SHEET 1 OF 1