

Center Position
A and B dump
to tank

To Reposition Handle:

1. Remove center screw
2. Take off and reposition handle
3. Apply low strength loctite to center screw
4. Torque center screw to 20 in-lbs


To Panel Mount Valve:

1. Remove center screw
2. Take off handle and panel nut
3. Position valve in panel and tighten panel nut
4. Replace handle
5. Apply low strength loctite to screw and torque to 20 in-lbs

OR

1. Use screw holes in bottom of base to mount valve.
(metric uses M5x0.8 and inch uses 10-24 bolts)

P-Blocked Center Valve to be used with
double acting systems using a pallet decoupler

INSTALLATION INSTRUCTIONS		 VEKTEK VEKTEK, INC. 1334 E. SIXTH AVE. P.O. BOX 625 EMPORIA, KS. 66801 U.S.A.	
		INSTRUCTION SHEET, VALVE, MNL, PANEL MNT, 3/4, PBC	
ASSEMBLIES AFFECTED		SIZE	REV
71-3474-01		A	A
43-1347-41		1S7125	
		FORM FEG041-IS-ASIZE, REV. B	

A	3892	RELEASE	ALS	08/08/19
REV	IN ACCORDANCE WITH ECN	EFFECTIVE DATE	REVISED BY	DATE
DRW BY:	ALS	DRAWING STATUS: Released PRODUCTION APPROVED FOR RELEASED STATUS ONLY		
DATE:	08/08/19			

SHEET 1 OF 1