







NO	QTY	PART NO	DESCRIPTION	STD SEAL KIT	LIGHT SPRING KIT	HEAVY SPRING KIT
1	1	23350096	SPRING, COMPRESSION			X
2	2	39051079	O-RING, (6mm X 1)	X		
3	2	39051087	O-RING, (4mm X 3)	X		
4	1	39051091	O-RING, (7.5mm x 1.5)	X	X	X
5	1	39051100	O-RING, (24.5mm X 2)	X		
6	1	39051106	O-RING, (19.5mm X 2)	X		
7	1	39053049	WIPER, PRESS-IN, 15mm	X		
8	1	81000000	CONTACT BOLT, WS, 7MPa, 5.5 & 10kN			
9	2	81400200	PLUG, MANIFOLD, 7MPa, M6			
10	1	23350095	SPRING, COMPRESSION		X	
N/A	N/A	L6010002	KIT, SEAL, WS, 7MPa, TF, SPR, 5.5kN	NOTED	N/A	N/A
N/A	N/A	L6110000	KIT, SPRING, WS, 7MPa, SPR, 5.5kN	N/A	NOTED	N/A
N/A	N/A	L6110001	KIT, SPRING, WS, 7MPa, SPR, 5.5kN	N/A	N/A	NOTED
N/A	N/A	ISL1000	INSTRUCTION SHEET, WS, 7MPa, TF, SPR, 5.5kN	N/A	N/A	N/A




TORQUE TO 1.3 Nm (11 IN. LBS)



TORQUE TO 30 Nm (20 FT. LBS)


See Instruction Sheet ISL1000 For Service Instructions.
Lubricate All Seals With Clean Hydraulic Oil Prior To Assembly.
Do Not Use Silicone Base Lubricants.



PARTS LIST	 VEKTEK, INC. 1334 E. SIXTH AVE. P.O. BOX 625 EMPORIA, KS. 66801 U.S.A.	
	PARTS LIST, ASSY, WS, 7MPa, TF, SPR, 5.5kN	
ASSEMBLIES AFFECTED	SIZE A	REV C
L1-0115-00H L1-0115-00L	LPL1000	

C	3849	RELEASE	MJUST	7/8/19
REV	IN ACCORDANCE WITH ECN	EFFECTIVE DATE	REVISED BY	DATE
DRW BY: N.KARRAS	DRAWING STATUS: Released			
DATE: 03/20/14	PRODUCTION APPROVED FOR RELEASED STATUS ONLY			

SHEET 1 OF 1



No.	DESCRIPTION
1	CONTACT BOLT
2	O-RING (7.5MM X 1.5)
3	PLUNGER
4	SPRING
5	WIPER
6	TOP CAP
7	O-RING (31.5MM X 2)
8	O-RING (25MM X 2.65)
9	COLLET ASSY
10	SPRING
11	BOTTOM CAP
12	BODY
13	O-RING (19.5MM X 2)
14	O-RING (24.5MM X 2)
15	O-RING (4MM X 3)
16	MANIFOLD PLUG
17	O-RING (6MM X 1)
18	G1/8 PLUG
19	BREATHER
20	WASHER
21	SHCS

TOOL LIST			
<input type="checkbox"/>	11mm & 13mm Open End Wrench		
<input type="checkbox"/>	2.5mm & 3mm Hex Key		
<input type="checkbox"/>	Vektek #ATL10312 Spanner Wrench		

INSTALLATION INSTRUCTIONS

VEKTEK, INC.
1334 E. SIXTH AVE. P.O. BOX 625
EMPORIA, KS. 66801 U.S.A.

A	2629	RELEASE	Twa	4/9/14
REV	IN ACCORDANCE WITH ECN	EFFECTIVE DATE	REVISED BY	DATE
DRW BY:	N. KARRAS	DRAWING STATUS: Released		
DATE:	3/10/14	PRODUCTION APPROVED FOR RELEASED STATUS ONLY		

ASSEMBLIES AFFECTED
LI-0115-00H
LI-0115-00L

INSTRUCTION SHEET, WS, 7MPo, TF, SPR, 5.5kn	
SIZE A	ISL1000
REV A	


Read all instructions before disassembly

Refer to the illustration on page 1 for component part numbers and tool list

Disassembly


1. Remove work support from fixture. Wipe clean to remove external contaminants.
2. With 13mm wrench at plunger (3) and 11mm wrench at contact bolt (1), unscrew contact bolt (1) from plunger (3). Remove O-ring (2) from contact bolt (1).
3. Remove contact spring (4) from inside plunger (3).
4. Insert 2.5mm hex key into cap screw (21) inside plunger (3) and unscrew cap screw (21). Remove cap screw (21) and washer (20) from inside plunger (3).
5. Gently slide plunger (3) out from top of work support.
6. Clamp work support body (12) in vise with bottom side facing up.
7. Using Vektek #ATL10312 spanner wrench unscrew bottom cap (11) from work support body (12). Remove O-ring (13) and O-ring (14) from bottom cap (11).
8. Remove work support body (12) from vise.
9. Remove wiper (5) from top cap (6). Be careful not to damage wiper bore or bore below wiper (6).
10. If work support hydraulics or vent is manifold fed from fixture, remove O-ring (15) from manifold s'face on work support body (12) mounting flange (2 places).
11. If work support hydraulics or vent is not manifold fed, insert 3mm hex key into plug (16) located at work support body (12) mounting flange and unscrew plug (16) (2 places). Remove O-ring (17) from plug (16).
12. Thoroughly clean contact bolt (1), contact spring (4), plunger (3), cap screw (21), washer (20), bottom cap (11), plugs (16) and set aside to dry.
13. Wipe clean bottom cap seal bore and seal face located in bottom of body (12). Wipe clean wiper bore located in top cap (6) at top of work support. Wipe clean manifold s'face located on body (12) mounting flange.

Caution: Do not expose work support clamping mechanism (9) located underneath the top cap (6) to any type of cleaning solutions. Removal of top cap (6) or clamping mechanism (9) terminates product warranty.

		
VEKTEK, INC. 1334 E. SIXTH AVE. P.O. BOX 625 EMPORIA, KS. 66801 U.S.A.		
INSTRUCTION SHEET, WS, 7MP, TF, SPR, 5.5kN		
SIZE A	ISL1000	REV A
FORM FEG041-1S-ASIZE, REV. B		

Assembly

1. Lubricate new O-rings (2), (13), (14), (15), (17) and outside diameter of new wiper (5) with clean hydraulic oil (Vektek 65-0010-01 or equivalent). Also, apply light film of hydraulic oil to outside surface of plunger (3)
2. Press wiper (5) into top cap (6) taking extra care to install squarely without excess force. CAUTION: IMPROPER INSTALLATION COULD DAMAGE WIPER (5) CAUSING EXCESS WIPER DRAG.
3. Install O-ring (13) and O-ring (14) onto bottom cap (11)
4. Clamp work support body (12) into vise with bottom side facing up.
5. Screw bottom cap (11) into bottom of work support body (12). Using Vektek #ATL10312 spanner wrench torque bottom cap (11) to 30 N-m (20 ft-lb).
6. Remove work support body from vise and position with top cap upward.
7. Gently install plunger (3) into work support through wiper (5) taking care not to damage wiper (5). Plunger (3) should move freely without binding. Lightly push plunger (3) downward until bottoms.
8. Install washer (20) onto cap screw (21) and drop thread side down into hole through top of plunger (3). Insert 2.5mm hex key into cap screw (21) and torque to 2.5 N-m (20 in-lb).
9. Insert contact spring (4) into hole through top of plunger (3). Contact spring (4) will pilot onto cap screw (21).
10. Install O-ring (2) onto contact bolt (1).
11. Screw contact bolt (1) into top of plunger (3). With 13mm wrench at plunger (3) and 11mm wrench at contact bolt (1) torque to 9 N-m (80 in-lb).
12. If work support hydraulics or vent is manifold fed from fixture, install new O-ring (15) into manifold surface on work support body (12) mounting flange (2 places).
13. If work support hydraulics or vent is not manifold fed install O-ring (17) onto plug (16), insert 3mm hex key into plug (16) and torque to 3 n-m (25 in-lb) (2 places).

		
VEKTEK, INC. 1334 E. SIXTH AVE. P.O. BOX 625 EMPORIA, KS. 66801 U.S.A.		
INSTRUCTION SHEET, WS, 7MP, TF, SPR, 5.5kN		
SIZE A	ISL1000	REV A
FORM FEG041-1S-ASIZE, REV. B		

SHEET 3 OF 3